

Backpack Flag Mount Installation Instructions



1) Install:

Cut down your fiberglass rod to your desired height using a cut off wheel or a fine tooth saw. If you are using a fine tooth saw place electrical tape around the end you are cutting to prevent the fiberglass rod from coming unraveled. We recommend cutting the rod down to ~48" tall.

Insert the fiberglass rod into the correct hole in the 3-D printed flag mount. Secure the top of the rod using the provided zip tie and cut off the excess.

If you are using a backpack with zippers you will need to use the provided double ended carabiner to keep the zippers closed, as they will open up under heavy riding.



Dirt Church Industries appreciates your order.

Please take the time to leave us a review.

Questions during the assembly of this kit, we can be reached at sales@dirtchurchindustries.com.