

Headlight Knob Extension For EXC/XC-W KTM & TE/FE (non-S) Husqvarna Installation Instructions



1) Install:

Unscrew your factory light switch knob, then install the Dirt Church Industries machined knob. **Note:** blue Locktite brand adhesive thread locker has been installed and will cure once fitted on your bike.



Dirt Church Industries appreciates your order!

Questions during the assembly of this kit or, have design feedback please reach out to us at sales@dirtychurchindustries.com

